# HDMI 1\*4 Splitter USER MANUAL

**P/N: HDSP04V15** 

## 1.Description

The HDMI Splitter is divided into fourHD video signals from the HD video source. Support for EDID adaptive feature that can adapt to a variety of complex application environments. The device has excellent image processing and transmission capacity, which makes the distribution of signals more fluid and stable. It is a reliable, high-performance and efficient way of distributing HDMI signals.

#### 2.Features

- Divide the high definition video source into four high definition video signals;
- High definition video signal resolution up to 3840\*2160@30 Hz;
- Compliance with HDMI 1.4 and HDCP 1.2 standard;
- Automatic adaptation EDID, can auto-match source and display device;
- Built-in automatic adjustment system, make the image smooth, clear and stable;
- Built-in ESD protection system;
- Simple to install, plug and play;

## 3.Package list


HDMI 1*4 Splitter	1 pcs
Power supply	1 pcs
User manual	1 pcs

Warranty Card	1 pcs
Warranty Card	1 pcs

# **4.**Specifications

	Parameter	Description
Video	Standards	HDMI 1.4; HDCP 1.2
	Maximum pixel clock	225MHz
	Maximum data rate	10.2Gbps
	Resolution	Max 3840*2160@30Hz
	Connector	HDMI-A
	Impedance	100Ω
	Recommended maximum input/output distance for HDMI.	Less than 5 meters, at 1920x1080@60hz.
Other	Power supply	The power adapter: DC 5V
	Power dissipation	MAX 3W
	Temperature	Operating: $-5^{\circ}$ ~ +70 $^{\circ}$ C
	Humidity	Operating: 5% ~ 90%
	Dimension	92.48*62.18*17.8mm
	The warranty	1 year free warranty

## 5.Panel




Port name	Description	
OUTPUT1-OUTPUT4	HDMI signal output.	
INPUT	HDMI signal input.	
DC 5V	Power adapter input.	
LED indicator	Description	
1-4	Output interface indicator light (light: have access monitor, extinguishing: no output state)	
PWR	Power indicator light (light: normal power supply, out: no power input)	
OUT1-OUT2	Output interface indicator light (light: have access monitor, extinguishing: no output state)	

## **6.Installation**

- 1、 INPUT the HDMI signal source into the HDMI1\*4 Splitter,
- 2、 Connect the display device (such as HDTV, splicing screen, etc.) to output1-output4,
- **3.** Connect the HDMI1\*4 distributor to the power supply, and the system will operate normally when the indicator light is on.

## 7.Diagram



### 8. Warranty

Thank you very much for using our products.

The warranty time is one year and life-long maintenance. During this period, any belongs to under normal usage circumstance cause because of the product quality's problem of breakdown, our company will be responsible for giving free maintain.

Free maintain won't be given under the following circumstance:

- The malfunction and damaged caused by incorrect use, the unauthorized repairs and alteration;
- The damage caused by fire, flood, abnormal voltage, other natural disasters and secondary product damage;
- The product malfunction caused by not in accordance with the user manual operation;
- The malfunction and damaged caused by the other barriers(man-made factors or external device);